

Remote Control Operation Guide

HEAD AND FOOT ADJUSTMENTS (A,E)

Adjusts the head and foot sections to the desired positions.

ZERO GRAVITY (B)

Allows your legs to be lifted to a position slightly above the chest, which enables blood flow to easily circulate back to the heart, thus reducing stress and fatigue.

FLAT (C)

Returns both head and foot to the flat position.

LOCKOUT FEATURE (D)

Locks the remote to prevent unintended use of the base.

Activating Remote Lockout

Press and hold the LOCK button for 3 seconds. The LED will flash twice to indicate activation. Pressing any buttons on the remote while in lockout mode will result in no movement from the power base.

Deactivating Remote Lockout

Repeat the same process, press and hold the LOCK button for 3 seconds. The LED will flash twice to indicate deactivation. The remote and power base will work normally.

A. RAISE & LOWER HEAD SECTION

B. ZERO GRAVITY

C. FLAT

D. LOCKOUT FEATURE

E. RAISE & LOWER FOOT SECTION

F. MEMORY POSITION 1

G. MEMORY POSITION 2


H. MEMORY POSITION SET

I. HEAD MESSAGE INTENSITY

J. MESSAGE TIMER

K. NIGHTLIGHT ON/OFF

L. FOOT MESSAGE INTENSITY



MEMORY POSITION PRESETS (F,G)

You can store 2 personalized memory positions. Press and hold the SET button for 5 seconds until the LED light flashes 3 times to store the setting. To recall a Memory Position, press the corresponding button.

NOTE: Do not hold the memory position for more than 5 seconds or the setting will overwrite.

MEMORY POSITION SET (H)

Return both head and foot to the flat position.

NIGHTLIGHT ON/OFF (K)

Toggle the lightbulb button for on/off functions.

Only available on O400

HEAD AND FOOT MESSAGE CONTROLS (I,L)

Turns on the corresponding message unit and slowly increases or decreases message intensity.

NOTE: The lowest setting will turn off the corresponding message unit.

MESSAGE TIMER (J)

Cycles through a 15, 30, or 45 minute timer.

NOTE: Any control button on the remote will interrupt and stop the FLAT, ZERO-G, Anti-Snore and Memory Position presets.