


## Headboard Bracket Installation

1. Use the remote control to raise the head of the base in order to gain access to the power base frame.
2. Remove plastic cap and place the Inner Headboard Bracket (D) into the round tube frame making sure the bracket inserted into the round tube. This will create a box shape. Place the Headboard Bracket Bolt (G) with a 5/16 Inch Washer (J) through the pre-drilled hole in the round tube frame and pass it through the Inner Headboard Bracket. Use the 5/16 Inch Washer (J) and the 5/16 Inch Bracket. Use the 5/16 Inch Washer (J) and 5/16 Inch (K) and tighten the bolt in place. Repeat for the opposing side of the power base frame.



3. Place the open side of the outer headboard bracket (E) onto the exposed square tube of the inner headboard bracket (D). This will create a tight fit between (D) and (E). Place a Headboard Bracket Bolt (G) with a 5/16 Inch Washer (J) through the Outer Headboard Bracket (E) and into Inner Headboard Bracket (D). Use a 5/16 Inch Washer (J) and 5/16 Inch Locking Nut (K) and hand tighten to allow for adjustment. Repeat same procedure for opposing side of the power base frame.

4. Firmly tighten the headboard bolts (not included) to the end of the headboard bracket assembly.
5. Measure the distance of the center to center mounting holes in the headboard.
6. Measure the distance of the center to center mounting holes in the headboard bracket assemblies.
7. If the headboard brackets require adjustments, loosen the bolts that are holding the outer headboard brackets and move them to the necessary distance. Reinstall the bolts and firmly tighten.

### STEP 11

Place your mattress on top of your power base.

Typical **Reverie 7T Power Base** is now complete. If the power base is equipped with a programmable setting or options, refer to the Remote Control Guide for more information.