


PARTS LIST

- A. Inner Headboard Bracket (2)
- B. Outer Headboard Bracket (2)
- C. 40L Bracket Bolt (4)
- D. 58L Bracket Bolt (4)
- E. 5/16 Inch Washer (16)
- F. 5/16 Inch Locking Nut (8)
- G. Wrench (1)
- H. Allen Wrench (1)



STEP 1

Use the hand control to raise the head of the foundation in order to gain access to the foundation.




STEP 2

Remove plastic cap and place the Inner Headboard Bracket (A) into the round tube foundation making sure the bracket is inserted into the round tube.



This will create a box shape. Place the Headboard Bracket Bolt (D) with a 5/16 Inch Washer (E) through the pre-drilled hole in the foundation and pass it through the Inner Headboard Bracket. Use the 5/16 Inch Washer (E) and 5/16 Inch Locking Nut (F) and tighten the bolt in place. Repeat for the opposing side of the foundation.



Repeat for the opposing side of the foundation.

STEP 3

Place the open side of the outer headboard bracket (B) onto the exposed square tube of the inner head board bracket (A). This will create a tight fit between (A) and (B). Place a Headboard Bracket Bolt (C) with a 5/16 Inch Washer (E) through the Outer Headboard Bracket (B) and into the Inner Headboard Bracket (A). Use a 5/16 Inch Washer (E) and 5/16 Inch Locking Nut (F) and hand tighten to allow for adjustment. Repeat same procedure for opposing side of the adjustable foundation.



STEP 4

Ensure the headboard bracket is assembled a distance of 1.5 (38.1 mm) to 2 inches (50.8 mm) between the edge of the foundation and the headboard bracket assemblies.



STEP 5

Firmly tighten the headboard bolts (not included) to the end of the headboard bracket assembly.

STEP 6

Measure the distance of the center to center mounting holes in the headboard.

STEP 7

Measure the distance of the center to center mounting holes in the headboard bracket assemblies.

STEP 8

If the headboard brackets require adjustments, loosen the bolts that are holding the outer headboard brackets and move them to the necessary distance. Reinstall the bolts and firmly tighten.